

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
080BA9S120LB	LED - White 120V
080BA9S120LG	LED - Yellow/Amber 120V
080BA9S120LR	LED - Red 120V
080BA9S120LV	LED - Green 120V
080BA9S24LB	LED - White 24V
080BA9S24LG	LED - Yellow/Amber 28V
080BA9S24LR	LED - Red 28V
080BA9S24LV	LED - Green 28V
23P-1040	Coil cutout switch
23P-1085	Stationary contact 400 A - ZTS40
23P-1086	Movable contact 400 A - ZTS40
23P-1087	Arc grid - 400 A - ZTS40
23P-1088	Solenoid hardware 400 A - ZTS40
23P-1092	Solenoid hardware 600 A - ZTS60
23P-1096	Solenoid hardware 800-1200 A - ZTS80-ZTS120
23P-1157	Movable contact kit
23P-1327	1-A4 Aux contact LZTS/ZBTS
23P-1328	2-A4 Aux contact LZTS/ZBTS
23P-1331	SE switch ZTS61-121 (replaced by L-3060RPL)
23P-1332	SN switch ZTS61-121 (replaced by L-3061RPL)
23P-1333	1-A3 Aux contact LZTS/ZBTS
23P-1334	2-A3 Aux contact LZTS/ZBTS
23P-1344	Movable contact Assy kit ZTS301
23P-1352	1-A3 Aux contact ZTS161/301
23P-1353	2-A3 Aux contact ZTS161/301
23P-1355	A3 Aux contact
23P-1356	1-A4 Aux contact ZTS161/301
23P-1357	2-A4 Aux contact ZTS161/301
23P-1359	A4 Aux contact
23P-1366	Arc grid 600-1200 AMP Replaces 23P-1091 23P-1095 23P-1366W (1 grid)
23P-1389	1-A3 Aux contact -ZTSD
23P-1390	2-A3 Aux contact -ZTSD
23P-1393	1-A4 Aux contact -ZTSD
23P-1394	2-A4 Aux contact -ZTSD
23P-1397	SN/SNO - SE/SEO ZTSD
23P-1400	Movable contact Assy kit ZTS161-201
23P-1402	A4 switch ZTSD161-301
23P-1404	A3 switch ZTSD161-301
23P-1434Y	Stationary contact Assy kit ZTS161-201
23P-1434Z	Stationary contact Assy kit ZTS301
23P-1452	SE switch ZTS81-121
23P-1461	Movable contact kit 600 AMP - ZTS60 (Horizontal) replaces 23P-1090 See Note 1 (1 contact)
23P-1462	Stationary contact kit 600 AMP - ZTS60 (Horizontal) replaces 23P-1089 See Note 1 (1 contact)
23P-1463	Movable contact kit 800-1200 AMP - ZTS80 - ZTS120 (Horizontal) replaces 23P-1094XYZ See Note 1 (1 contact)
23P-1470	Movable contact kit 600 AMP ZTS61 For use only on units shipped after 7/1/86 consult factory for exact dates ZBTS61 (All) N-Neutral pole only (1 contact)
23P-1471	Stationary contact kit 600 AMP - ZTS61 For use only on units shipped after 7/1/86 consult factory for exact dates ZBTS61 (All) (1 contact)
23P-1533	Switch assembly
23P-1534	Switch assembly

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
23P-1535	Switch assembly
23P-1536	Switch assembly
23P-1540	Switch assembly
23P-1541	Switch assembly
23P-1568	Switch assembly
23P-1569	Switch assembly
23W-3007G	Harness - start relay 250
26P-1144	Contact assembly
26P-1299	Bypass speed wrench ZBTS41-121
26P-1303	ZBTS - 2nd generation bypass control panel
26P-1304	Switch assembly
26P-1311	Switch assembly
26P-1312	Switch assembly
26P-1327	SN/SNO switch ZTSD81-121
26P-1328	SE/SEO switch ZTSD81-121
26P-1331	Movable contact kit 800-1200 AMP ZBTS81-121 A B & C Phase. For use on units shipped prior to 1/1/85. Consult factory for exact dates and application prior to order - replaces 23P-1367 X Y Z (1 contact).
26P-1332	Movable contact kit 800-1200 AMP ZBTS81-121 N (Neutral) phase. For use on units shipped prior to 2/18/85. Consult factory for exact dates and application prior to order (1 contact).
26P-1333	Stationary contact kit 800-1200 AMP - ZBTS81-121. For use on units shipped prior to 2/18/85. Consult factory for exact dates and application. prior to order (1 contact).
26P-1334	Movable contact kit 800-1200 AMP ZTS/D ZBTS81-121 A B & C phase. For use on units shipped after 2/18/85. Consult factory for exact dates and application prior to order (1 contact).
26P-1335	Movable contact kit 800-1200 AMP ZBTS/D ZTS/D ZBTS81-121 N(neutral) phase. For use on units shipped after 2/18/85. Consult factory for exact dates and application prior to order (1 contact).
26P-1336	Stationary contact kit 800-1200 AMP ZBTS/D ZTS/D ZBTS81-121 N(neutral) phase. For use on units shipped after 2/18/85. Consult factory for exact dates and application prior to order (1 contact).
26W-3027G	Bypass Harness
26W-3026G	Power Panel Harness
27H-1002	Normal lug plate SZTS
27H-1003	Emergency lug plate SZTS
27P-1004	Stationary contact - 150-260 A
27P-1014	Arc grid
27P-1015	Load carrier
27P-1016	Load carrier
27P-1017	Load carrier
27P-1018	Emergency stationary contact support block 40-260 Amp
27P-1019	Normal stationary contact support block 40-260 Amp
27P-1033	Stationary contact - 40-100 A
27P-1036	Movable contact - 40-100 A
27P-1037	Movable contact - 150-260 A
27P-1049	Stationary contact - 400 A - ZTS41
27P-1060	Arc grid - 400 A - ZTS41
27P-1063	Movable contact - 400 A - ZTS41
27P-1065Z	Capacitor replacement kit for PS-4017
27P-1142	Arc chute
43050	Synch Light
46P-1079	Bypass control panel "H" bypass
46P-1100A	ZTSH/ZBTSH Transfer Switch Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 100 Amp
46P-1100B	ZTSH/ZBTSH Transfer Switch Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 150 Amp
46P-1100C	ZTSH/ZBTSH Transfer Switch Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 225 Amp

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
46P-1100D	ZTSH/ZBTSH Transfer Switch Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 260 Amp
46P-1100E	ZTSH/ZBTSH Transfer Switch Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 400 Amp
46P-1101A	ZTSH/ZBTSH Transfer Switch Contacts - Normal neutral phase 1 set of 1 movable and stationary contact 100 Amp
46P-1101B	ZTSH/ZBTSH Transfer Switch Contacts - Normal neutral phase 1 set of 1 movable and stationary contact 150 Amp
46P-1101C	ZTSH/ZBTSH Transfer Switch Contacts - Normal neutral phase 1 set of 1 movable and stationary contact 225 Amp
46P-1101D	ZTSH/ZBTSH Transfer Switch Contacts - Normal neutral phase 1 set of 1 movable and stationary contact 260 Amp
46P-1101E	ZTSH/ZBTSH Transfer Switch Contacts - Normal neutral phase 1 set of 1 movable and stationary contact 400 Amp
46P-1102A	ZTSH/ZBTSH Transfer Switch Contacts - Emergency (ABC phases) 1 set of 3 movable and stationary contacts 100 Amp
46P-1102B	ZTSH/ZBTSH Transfer Switch Contacts - Emergency (ABC phases) 1 set of 3 movable and stationary contacts 150 Amp
46P-1102C	ZTSH/ZBTSH Transfer Switch Contacts - Emergency (ABC phases) 1 set of 3 movable and stationary contacts 225 Amp
46P-1102D	ZTSH/ZBTSH Transfer Switch Contacts - Emergency (ABC phases) 1 set of 3 movable and stationary contacts 260 Amp
46P-1102E	ZTSH/ZBTSH Transfer Switch Contacts - Emergency (ABC phases) 1 set of 3 movable and stationary contacts 400 Amp
46P-1103A	ZTSH/ZBTSH Transfer Switch Contacts - Emergency neutral phase 1 set of 1 movable and stationary contact 100 Amp
46P-1103B	ZTSH/ZBTSH Transfer Switch Contacts - Emergency neutral phase 1 set of 1 movable and stationary contact 150 Amp
46P-1103C	ZTSH/ZBTSH Transfer Switch Contacts - Emergency neutral phase 1 set of 1 movable and stationary contact 225 Amp
46P-1103D	ZTSH/ZBTSH Transfer Switch Contacts - Emergency neutral phase 1 set of 1 movable and stationary contact 260 Amp
46P-1103E	ZTSH/ZBTSH Transfer Switch Contacts - Emergency neutral phase 1 set of 1 movable and stationary contact 400 Amp
46P-1104A	ZBTSH Bypass Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 100 Amp
46P-1104B	ZBTSH Bypass Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 150 Amp
46P-1104C	ZBTSH Bypass Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 225 Amp
46P-1104D	ZBTSH Bypass Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 260 Amp
46P-1104E	ZBTSH Bypass Contacts - Normal (ABC phases) 1 set of 3 movable and stationary contacts 400 Amp
46P-1105A	ZBTS Bypass Contacts - Normal Neutral Phase 1 set of 1 movable and stationary contact 100 Amp
46P-1105B	ZBTS Bypass Contacts - Normal Neutral Phase 1 set of 1 movable and stationary contact 150 Amp
46P-1105C	ZBTS Bypass Contacts - Normal Neutral Phase 1 set of 1 movable and stationary contact 225 Amp
46P-1105D	ZBTS Bypass Contacts - Normal Neutral Phase 1 set of 1 movable and stationary contact 260 Amp
46P-1105E	ZBTS Bypass Contacts - Normal Neutral Phase 1 set of 1 movable and stationary contact 400 Amp
46P-1132	Switch assembly
46P-1161	Switch assembly
47P-1053	SSRCP control panel (Note: use jumpers PS-5067)
50P-1005	RT box - ZTSL 120V NOTE: For mini RT box
50P-1006	RT box - ZTSL 208/220V used with new style
50P-1007	RT box - ZTSL 230/240V 40-150Amp standard
50P-1008	RT box - ZTSL 277V ATS see 57P series
50P-1009	RT box - ZTSL 380/400V
50P-1010	RT box - ZTSL 416/440V
50P-1011	RT box - ZTSL 460/480V
50P-1012	RT box - ZTSL 575/600V
50P-1013	RT box - ZTGDK 120V
50P-1014	RT box - ZTGDK 208/220V
50P-1015	RT box - ZTGDK 230/240V
50P-1016	RT box - ZTGDK 277V
50P-1017	RT box - ZTGDK 380/400V
50P-1018	RT box - ZTGDK 416/440V
50P-1019	RT box - ZTDGK 460/480V
50P-1020	RT Box - ZTGDK 575/600V

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
50P-1034	RT box - ZTSDL 120V
50P-1035	RT box - ZTSDL 208/220V
50P-1036	RT box - ZTSDL 230/240V
50P-1037	RT box - ZTSDL 277V
50P-1038	RT box - ZTSDL 380/400V
50P-1039	RT box - ZTSDL 416/440V
50P-1040	RT box - ZTSDL 460/480V
50P-1041	RT box - ZTSDL 575/600V
50P-1049	Lon Works Annunciator Module
50P-1054	Lon Works Card (MX-100)
50P-1055	Lon Works Card (MX-150/200/250)
50P-1057	Lon Works Annunicator (1-8 position)
50P-1087	Time delay board (ZTXR) 120/240V
50P-1090	Time delay board (ZTXR) 208V
50P-1105	Modbus Communications Card
50P-1124	Modbus Configuration Kit - DISCONTINUED AND REPLACED WITH 50W-1208
50P-1160RPL	MX100/150 Field Replacement Kit - Factory Programmed
50P-1160SPR	MX100/150 Replacement Spare Controller Kit
50P-1161RPL	MX200/250 Field Replacement Kit - Factory Programmed
50P-1161SPR	MX200/250 Replacement Spare Controller Kit
50P-1212	Bypass Transformer Board
50P-1213	Bypass Transformer Board
50P-1220	Bypass Logic Board
50P-1224	CPS Box - 120 volt
50P-1225	CPS Box - 208/220 volt
50P-1226	CPS Box - 230/240 volt
50P-1227	CPS Box - 277 volt
50P-1228	CPS Box - 380/400 volt
50P-1229	CPS Box - 416/440 volt
50P-1230A	CPS Box - 460/480 volt
50P-1231RPL	CPS Box - 575/600 volt
50P-1242	Limit Switch
50P-2000	OBSOLETE See 50P-3000 ZTX - MX-50 board (complete) 1 phase 208/240
50P-2003	OBSOLETE NO REPLACMT ZTX Gen control board
50P-2005	OBSOLETE See 50P-3031 ZTX - MX50 3 phase sensing adder board (208/240)
50P-2006	OBSOLETE See 50P-3001 ZTX - MX-50 board (complete) 1 phase 380/416
50P-2008	OBSOLETE See 50P-3002 ZTX - MX-50 board (complete) 1 phase 440/480
50P-2009	OBSOLETE See 50P-3032 ZTX - MX50 3 phase sensing adder board (380/415)
50P-2010	OBSOLETE See 50P-3033 ZTX - MX50 3 phase sensing adder board (440/480)
50P-2012	OBSOLETE See 50P-3031 ZTX - MX50 3 phase base board (208/240)
50P-2013	OBSOLETE See 50P-3032 ZTX - MX50 3 phase base board (380/416)
50P-2014	OBSOLETE See 50P-3033 ZTX - MX50 3 phase base board (440/480)
50P-2019	OBSOLETE ZTX control interface printed circuit board See 50P-30XX MX-60 plus touch pad
50P-3000	ZTX - MX-60 BOARD (COMPLETE) 208/220/240 VOLT 50/60 Hz 1 PHASE
50P-3001	ZTX - MX-60 BOARD (COMPLETE) 380/416 VOLT 50/60Hz 1 PHASE
50P-3002	ZTX - MX-60 BOARD (COMPLETE) 440/480 VOLT 50/60Hz 1 PHASE
50P-3003	ZTX - MX-60 BOARD (COMPLETE) 120 VOLT 50/60Hz 1 PHASE
50P-3031	ZTX - MX-60 3 phase base board (208/220/240 VOLT)
50P-3032	ZTX - MX-60 3 phase base board (380/416 VOLT)
50P-3033	ZTX - MX-60 3 phase base board (440/480 VOLT)

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
50W-1000	J5 harness
50W-1100	J5 harness
50W-1208	Configurator Accessory - RS-232/485 adaptor for MX-200. Software must be downloaded. Replaces 50P-1124.
50W-1211	Configurator Accessory
57H-1011	Aux. switch cam
57H-1013	Solenoid clamp
57P-1015	Mini RT box - 3phase 120V
57P-1016	Mini RT box - 3phase 208/220V
57P-1017	Mini RT box - 3phase 240V
57P-1018	Mini RT box - 3phase 277V
57P-1019	Mini RT box - 3phase 380/400V
57P-1020	Mini RT box - 3phase 416/440V
57P-1021	Mini RT box - 3phase 460/480V
57P-1022	Mini RT box - 3phase 575/600V
57P-1115	Mini RT box - 1phase 120V
57P-1116	Mini RT box - 1phase 208/220V
57P-1117	Mini RT box - 1phase 240V
57P-1118	Mini RT box - 1phase 277V
57P-1119	Mini RT box - 1phase 380/400V
57P-1120	Mini RT box - 1phase 416/440V
57P-1121	Mini RT box - 1phase 460/480V
57P-1122	Mini RT box - 1phase 575/600V
57P-1158	Small wiring door, touch pad, ribbon cable, for 2002 and newer switches NEMR1 up to 2001 with screw on cover with touch pad mounted behind cover
57P-1159	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57P-1160	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57P-1161	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57P-1162	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57P-1163	Door assembly upgrade for 200 to 2001 NEMR1, 20X to 2000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57P-1164	Door assembly upgrade for 200 to 2001 NEMR1, 20X to 2000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
57W-1021	ZTX 40-225A harness
57W-1022	ZTX harness
57W-1026	ZTX Keypad connector
57W-1044	Power panel harness
57W-1045	Main wiring harness
58P-1084	ZTX 9V battery cable assembly
58P-1105	Cam module for delayed transition switch (F14B frame)
58P-1106	Secondary solenoid - delayed transition (F14B frame)-120
58P-1107	Secondary solenoid - delayed transition (F14B frame)-208
58P-1108	Secondary solenoid - delayed transition (F14B frame)-240
58P-1109	Secondary solenoid - delayed transition (F14B frame)-380/416
58P-1110	Secondary solenoid - delayed transition (F14B frame)-480
58P-1111	Secondary solenoid - delayed transition (F14B frame)-575/600
58P-1207	Touch pad panel, ribbon cable, for 2002 and newer switches 300A 400A with touch pad mounted to cover
58P-1213	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
58P-1214	Door assembly upgrade for 100 to 1001 NEMR1, 10X to 1000 for old style 27X switches with mixed, adapts to mixed controller. Includes new door assembly and new touch pad.
58W-1013	Harness - power panel 400A ZTX
58W-1014	Harness - power panel ZTX
BA9S160	Bulb 160VAC - Incand. min purchase 6
BA9S24	Bulb 24VAC - Incand. min purchase 6

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
CR420NPL0224	2-Pole Control Relays 24Vdc Coil
CR420NPL022J	2-Pole Control Relays 120VAC Coil
CR420NPL0444	4-Pole Control Relays 24Vdc Coil
E-3009	Trip Pin (for 2410 exercisor clock on day wheel)
E-3402	Manual operating handle shaft ZBTS40 (add PS-3496 grip)
E-4099	Manual operating handle shaft ZTS/ZTSH60-120 and 40-260A (Note - Add PS1586)
E-4113	Manual operating handle shaft ZTS400-600 (horiz.type)
E-4173	Manual operating handle shaft ZTS41 & ZBTS41-121 (Note - Add PS1586)
E-5123	Manual operating handle shaft ZTS160-300 (Note - Add PS2131)
F6-25RPL	C Exerciser clock 120V (solid state repl. assy for mechanical)
F6-26RPL	C Exerciser clock 208/240V (solid state repl. assy for mechanical)
F6-27RPL	C Exerciser clock 480V (solid state repl. assy for mechanical)
FT-2111	Solid State Repl. Assy for TFC (120VAC)
H3SAX	H Timer replaces FT-165 & FT-167
HMICABC111	Interface cable from OIP(MIP) to PLC
IC200CHS022	Versa Max I/O Carrier
IC200CPUE05	CPU VersaMax PLC w/ Ethernet Port
IC200MDD844	Mixed IO Module
IC200MDL650	32 pts digital input module
IC200MDL750	32 pts digital output module
IC200PWR002	Power supply for Versamax
IC693CMM311	Coprocessor communication module
IC693CPU350	CPU (To be used at the master section)
IC693MDL655	32 Point Input Card
IC693MDL753	32 Point Output Card
IC693PWR331	24Vdc Power Supply
K-1028	Buzzer - 115 V
K-1049	Relay - SPDT
K-1055	PR phase relay - 120 208V
K-1056	PR phase relay - 208 V OBSOLETE REPLACED BY K-1122RPL
K-1056A	PR phase relay - 240 V
K-1057	PR phase relay - 277 V
K-1058	PR phase relay - 480 V
K-1060	Relay - SPDT - 240 V
K-1061	Pneumatic timer
K-1086	Relay - DPDT - 120 V
K-1087	Relay - DPDT - 240 V
K-1088	Relay - DPDT - 480 V
K-1095	Coil control relay - 120 V
K-1097	Relay
K-1099	Control relay - 4PDT - 120 V
K-1120	Coil control relay - ZTS - 120 V
K-1120B	Coil control relay - DC Solenoid
K-1121 RPL	ARS-1 phase relay - 120 V replacement assy.
K-1122 RPL	ARS-2 phase relay - 208/240 V. Includes K-1186 relay, socket, clips. Specify 208V or 240V when ordering.
K-1123 RPL	ARS-3 phase relay - 277 V replacement assy.
K-1156RPL	R4 Inphase monitor replacement w/labels - 120V OBSOLETE WITH NO REPLACEMENT
K-1157RPL	R4 Inphase monitor replacement w/labels - 480V OBSOLETE WITH NO REPLACEMENT
K-1159RPL	R4 Inphase monitor replacement w/labels - 208 - 240V OBSOLETE WITH NO REPLACEMENT
K-1160RPL	ARS-4 phase relay - 480 V replacement assy.

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
K-1185	ARSM phase relay (plug in) - 120 V
K-1186	ARSM phase relay (plug in) - 208/240 V. Specify 208V or 240V when ordering.
K-1187	ARSM phase relay (plug in) - 277 V
K-1188	ARSM phase relay (plug in) - 480 V
K-1192 R	VFSM relay w/light
K-1192 RPL	120V VFSM field replacement assy.
K-1194	8 Pin miniature timer base
K-1196RPL	R4 Inphase monitor replacement w/labels - 120V OBSOLETE WITH NO REPLACEMENT
K-1197RPL	R4 Inphase monitor replacement w/labels - 480V OBSOLETE WITH NO REPLACEMENT
K-1198RPL	R4 Inphase monitor replacement w/labels - 380-416V OBSOLETE WITH NO REPLACEMENT
K-1199RPL	R4 Inphase monitor replacement w/labels - 208-240V OBSOLETE WITH NO REPLACEMENT
K-1200RPL	R4 Inphase monitor replacement w/labels - 575-600V OBSOLETE WITH NO REPLACEMENT
K-1201G	PMI 5-6 seconds replaces K-1201
K-1204	Relay - 4 point - RT/CR
K-1208	OBSOLETE Base Replaced with ZCCR420HA
K-1212	Relay (208-240) plug in
K-1228	Relay Base
K-1230	Solid state timer ZTS T U W
K-1232	Relay 24VAC
K-1233	Triple purpose relay - 120V
K-1234	Triple purpose relay - 208/240V
K-1235	Triple purpose relay - 480V
K-1237R	HX timer 3 sec
K-1240	Relay
K-1241	Timer cover
K-1242	Relay
K-1243	Synch check relay
K-1246	Phase sequence relay
K-1249	Timer
K-1259	Coil control relay - ZTS - 24V
K-1260	Coil control relay - ZTS - 24V
K-1265	Relay output dual module
K-1266	Relay/Opto input dual 24V
K-1267	Relay/Opto input dual 120V
K-1268	Relay 12V E start MX200
K-1270RPL	R4 Inphase monitor replacement w/labels - 575-600V
K-1276	C or D Clock 120V - G Type
K-1277	C/D Clock - G type
K-1278	C/D 365 Day clock - G type
K-1285	C or D Clock 7 Day 120V
K-1286	C or D Clock 7 Day 208/220/240V
K-1287	Fixed 20 sec Timer 120V
K-1288	Fixed 20 sec Timer 208/220/240V
K-1289	C/D Clock 7 Day 120V
K-1290	C/D Clock 7 Day (same footprint as Z2000-2A)
K-1299	C/D Clock 365 Day
K-1305	Relay
K-2003	Solenoid - 115 V
K-2006	Solenoid - 230 V
K-2011	Solenoid - Note use K-2149 for MT/6MT

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
K-2012	Solenoid
K-2013	Solenoid - 115 V
K-2014	Solenoid - 230 V
K-2015	Solenoid - 115 V
K-2016	Solenoid
K-2017F	Solenoid
K-2018	Solenoid - 230 V
K-2019	Solenoid
K-2020	Solenoid - 460/480 V
K-2021	Solenoid
K-2025	Solenoid
K-2026	Solenoid
K-2030	Solenoid - 460 V
K-2032	Solenoid - 208/220 V
K-2037	Solenoid - 440 V
K-2051	Solenoid
K-2052	Solenoid
K-2053	Solenoid
K-2054	Solenoid
K-2055	Solenoid
K-2056	Solenoid
K-2057	Solenoid
K-2058	Solenoid
K-2063	Solenoid
K-2070F	Solenoid
K-2071F	Solenoid
K-2072F	Solenoid
K-2073F	Solenoid
K-2074F	Solenoid
K-2078F	Solenoid Includes both "F" suffix used on
K-2079F	Solenoid
K-2080F	Solenoid ZTS61-121 and Non-Suffix units
K-2089	Solenoid OBSOLETE
K-2090F	Solenoid for ZTS60-120
K-2091F	Solenoid (K-2070 thru K-2099)
K-2092F	Solenoid
K-2093F	Solenoid
K-2094	Solenoid
K-2095F	Solenoid
K-2096	Solenoid
K-2097	Solenoid
K-2099	Solenoid
K-2104P	Linear actuator 120V w/plunger Benolex subpanel OBSOLETE
K-2104PN	Linear actuator 120V w/plunger new molded subpanel OBSOLETE
K-2105P	Linear actuator 240V w/plunger-Benolex subpanel OBSOLETE
K-2105PN	Linear actuator 240V w/plunger new molded subpanel OBSOLETE
K-2106	Linear actuator - 480 V - obsolete - use K-2119
K-2107P	Actuator plunger (3 Pole) 40A-260A old style w/plunger OBSOLETE
K-2108	Actuator plunger - (4 Pole) 40A-260A old style w/plunger OBSOLETE
K-2109P	Linear actuator 120V w/plunger Benolex subpanel OBSOLETE

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
K-2109PN	Linear actuator 120V w/plunger new molded subpanel OBSOLETE
K-2110P	Linear actuator 240 V w/plunger Benolex subppanel OBSOLETE
K-2110PN	Linear actuator 240V w/plunger new molded subpanel OBSOLETE
K-2111P	Linear actuator 480 V w/plunger Benolex subppanel OBSOLETE
K-2111PN	Linear actuator 480V w/plunger new molded subpanel OBSOLETE
K-2112	Solenoid - 120 V
K-2113	Solenoid - 208 V
K-2114	Solenoid - 240 V
K-2115	Solenoid - 480 V
K-2117	Solenoid
K-2119P	Linear actuator 480 V w/plunger Benolex subppanel OBSOLETE
K-2119PN	Linear actuator 480V w/plunger new molded subpanel OBSOLETE
K-2120	DC solenoid OBSOLETE
K-2123	DC solenoid
K-2125	DC solenoid OBSOLETE, replaced with K-2128
K-2126	DC solenoid
K-2127	DC solenoid
K-2128	DC solenoid, replaces K-2125
K-2129	DC solenoid
K-2130	DC solenoid
K-2132P	Linear actuator - 480 V w/plunger OBSOLETE
K-2133P	Linear actuator - 480 V w/plunger OBSOLETE
K-2134P	Linear actuator - 240 V w/plunger OBSOLETE
K-2135P	Linear actuator - 240 V w/plunger OBSOLETE
K-2136P	Linear actuator - 208 V w/plunger OBSOLETE
K-2137P	Linear actuator - 208 V w/plunger OBSOLETE
K-2138P	Linear actuator - 120 V w/plunger OBSOLETE
K-2139P	Linear actuator - 120 V w/plunger OBSOLETE
K-2140	Actuator plunger 400 amp OBSOLETE
K-2141P	Linear actuator 208V w/plunger Benolex subppanel OBSOLETE
K-2141PN	Linear actuator 208V w/plunger new molded subpanel OBSOLETE
K-2142P	Linear actuator 208V w/plunger Benolex subppanel OBSOLETE
K-2142PN	Linear actuator 208V w/plunger new molded subpanel OBSOLETE
K-2146	Solenoid ZTSD 61 AMP
K-2147	Solenoid ZTSD 81 101 121
K-2149	Solenoid - replaces K-2011 for MT/6MT
K-2151	ZTSD solenoid
K-2157	ZTSD solenoid
K-2158	ZTSD solenoid
K-2159	Bypass interlock solenoid
K-2160	ZTSD solenoid
K-2168	DC solenoid
K-2176RPL	ZTS/D solenoid 480 V
K-2177RPL	ZTS/D solenoid 208 or 240 V
K-2180	Solenoid CBN/CBE/BPS/TSR
K-2182	Solenoid 120-208 V MVP
K-2183	Solenoid 240-277 V MVP
K-2184	Solenoid 480 V MVP
K-2186	Solenoid 277 V
K-2187	DC solenoid

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
K-2188RPL	ZTS/D solenoid 380 V
K-2189RPL	ZTS/D solenoid 240 V
K-2192	Bypass interlock solenoid ZBTSH 1600-3000 Amp
K-2193	Solenoid
K-2195	Solenoid
K-2201	Actuator plunger (40-260A) 2/3pole new molded panel OBSOLETE
K-2202	Actuator plunger (40-260A) 4pole new molded panel OBSOLETE
K-2207	Solenoid 120V
K-2208	Solenoid 208V
K-2209	Solenoid 480V
K-2211	Solenoid 277V
K-2212	Solenoid 380/416 V
K-2213	Solenoid 575/600V
K-2214	Solenoid 480V
K-2215	Solenoid 208/240V
K-2216	Solenoid 380/416V
K-2217	Solenoid 575/600V
K-2228	Solenoid 240V
K-2229	Solenoid 120V
K-2230	Solenoid 208V
K-2231	Solenoid 240V
K-2232	Solenoid 277V
K-2233	Solenoid 380/415V
K-2234	Solenoid 480V
K-2235	Solenoid 575/600V
K-2246B	Solenoid 208/240 volt - F14
K-2248B	Solenoid 480 volt - F14
K-3005	Transformer - 440/120 V - 5 VA
K-3022	Transformer - 575/120 V - 10 VA
K-3025	Transformer - 240/120 V - 10 VA
K-3026	Transformer - 480/120 V - 10 VA
K-3028	Control transformer - 480/120 V - 150 VA
K-3029	Control transformer - 600/120 V - 150 VA
K-3030	Transformer 3 phase - 480/120 V - phase relays
K-3035	Transformer 3 phase - 575/120 V - phase relays
K-3041	Transformer - 240/480/120 V - 100 VA
K-3042	Transformer - 480/120 V - 45 VA
K-3051	Transformer - 240/480-120V 25VA (CTAP)
K-3053	Transformer - 208/120 V - 100 VA
K-3055	Transformer - 416/120 V - 100 VA
K-3056	Transformer - 208/120 V - 150 VA
K-3057	Transformer - 380/120 V - 150 VA
K-3058	Transformer - 416/120 V - 150 VA
K-3061	XFR 24/120/240 25 VA
K-3062	XFR 24/240/480 25 VA
K-3063	XFR 24/208/416 25 VA
K-3064	XFR 24/220/440 25 VA
K-3065	XFR 24/575
K-3066	XFR 24/600
K-3067	XFR 24/380

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
K-3068	XFR 100 VA - 120-120
K-3070	XFR 50 VA - 208/277 - 120
K-3071	XFR 50 VA - 240/480 - 120
K-3076	XFR 50 VA - 120-120
K-3081	XFR 5 VA - 277/120
K-3089	XFR 50 VA - 380/400-416 - 110/220
K-3092	Potential XFR
K-3095	Potential XFR
K-3096	Potential XFR
K-3102	XFR 10VA 208/24V
K-3103	XFR 10VA 240/24V
K-3104	XFR 10VA 277/24V
K-3105	XFR 10VA 480/24V
K-3107	XFR 10VA 575/24V
K-3108	ZTC control XFR - 220/240
K-3109	ZTC control XFR - 208
K-3110	ZTC control XFR - 380
K-3111	ZTC control XFR - 277
K-3112	ZTC control XFR - 575/600
K-3113	ZTC control XFR - 415
K-3114	ZTC control XFR - 120
K-3216	XFR 1VA 120V
K-3217	XFR 1VA 208V
K-3218	XFR 1VA 240V
K-3224	XFR 25VA 120V
K-3225	XFR 25VA 208V
K-3226	XFR 25VA 240V
K-4103	ZTX 12VDC battery charger 1.5 Amp (replaces K-4102)
L-1019	Switch block
L-1020	Switch block
L-1024	Switch block N.O. (bypass switch)
L-1025	PB operator black test switch (Tele)
L-1026	PB operator green YN (Tele)
L-1027	PB operator red YE (Tele)
L-1028	NO Contact Block (Tele)
L-1029	NC Contact Block (Tele)
L-2006	Toggle switch
L-2028	N/E FTO reset oper; key mom.
L-3002	Control relay switch
L-3003	Electric interlock switch
L-3019	Switch
L-3041	Switch
L-3046	Coil cutout switch - see L-3058 kit
L-3052	Limit switch BT/TSE/BLL/ALL
L-3054	Limit switch ATS latched 1600-3000 Amp
L-3056	Cam switch
L-3057	Switch
L-3058	Coil cutout switch kit
L-3060RPL	Coil cutout switch - ZTS
L-3061RPL	Coil cutout switch - ZTS

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
L-3071	Limit switch AA/AE/PLS
L-3078	Limit switch
L-3079	Limit switch SCN/SCE/CNE
L-3080	Limit switch SN/SE (ZBTSDH40)
L-3081	2 Pos. Maintained Keyed (Tele)
L-3087G	Limit switch - gold
L-3089	SNO/SEO Switches for delayed transition switch (F14B)
L-4003	Test switch operator
L-4006	Voltmeter switch
L-4007	Ammeter switch
L-4008	Control switch - PC
L-4009	D3 switch operator
L-4018	2 Position operator - maintained (Tele)
L-4019	2 Position key switch - maintained (Tele)
L-4020	2 Position key switch - momentary (Tele)
L-4022	3 Pos. Spring Return Keyed
L-4023	3 Pos. Spring Return
L-4024	3 Pos. Maintained
L-4027	Limit switch 600V
L-4031	3 Pos. Maintained Keyed
L-5021	Switch DPDT A3/A4 Aux contact - new style
L-5022F	Switch SPDT A3/A4 Aux contact - new style
L-5023	Switch DPDT NA4-EA3 Aux contact (ZBTSH40)
MM-511	Touchup paint (Zenith82 grey - NEMA 1)
MM-554	Touchup paint (Grey) spray can - Older Grey Color
MM-555	Touchup paint (IEC beige) spray can
MM-558	Touchup paint (IEC beige) liquid
MM-568	Ansi Grey 61-bottle
MM-590	Ansi Grey 61-Aerosol (must ship GROUND)
MNET000	Multinet Modbus to Ethernet Convertor
OSA-A	Solid state timer ZTS T U W
OSA-A3	Solid state timer ZTS T U W
OSA-A3	Solid state timer ZTS T U W (Replaces OSA-A2)
OSA-A-TFM	Solid state timer replacement MT 120V
OSA-C-TFM	Solid state timer replacement MT 240V
P9ACFS5	Opt. Flange for 5 Contact Blocks
P9B01VN	Normally Closed Contact
P9B10VN	Normally Open Contact
P9B11VN	N. Open N. Closed Contacts
P9PDMVD	Base & Bulb 24V Flashing
P9PDMVDLR	Base & Red LED 24V Flashing
P9PDNVO	Base (full voltage)
P9XLAD	Housing w/ Amber Lens
P9XLBD	Housing w/ White Lens
P9XLID	Housing w/ Clear Lens
P9XLRD	Housing w/ Red Lend
P9XLVD	Housing w/ Green Lens
P9XPGD	Housing w/ Yellow Lens
P9XPNG	Black Flush Pushbutton
P9XSCD0A95	2 Pos. Maintained Keyed

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
P9XSCD0K95	2 Pos. Maintained Keyed
P9XSCD3C95	3 Pos. Spring Return Keyed
P9XSCD5A95	2 Pos. Spring Return Keyed
P9XSCZ0C95	3 Pos. Maintained Keyed
P9XSMD0N	2 Pos. Maintained
P9XSMZ0N	3 Pos. Maintained
P9XSMZ3N	3 Pos. Spring Return
PS-1231	Condenser
PS-1254	Socket (Pilot Light)
PS-1255	Red Lens (Pilot Light)
PS-1256	Green Lens (Pilot Light)
PS-1270	Bulb (ZTS Emergency Position) min purchase 6
PS-1271	Bulb (ZTS Normal Position) min purchase 6
PS-1272	Blinking light for shunt trip
PS-1362	Condenser
PS-1375	Capacitor
PS-1586	Manual operating handle knob (40-1200)
PS-1755	Terminal Block 12 point
PS-1756	Terminal Block 15 point
PS-1828	Terminal Block 13 point
PS-2131	Manual operating handle grip (1600-3000)
PS-2422	Control Panel Cover 12x29
PS-2423	Control Panel Cover 12x41
PS-2432	Control Panel Cover 22x29
PS-3013	Stationary contact screw
PS-3080	OSA Timer clip (2 required) min purchase 2
PS-3156	Clip min purchase 2
PS-3472	Adapter ring kit for reduction of 1 3/16 to 7/8 hole
PS-3473	Contact block mounting base. Required for all Tele.
PS-3496	Handle grip
PS-3504	Roller
PS-3549	Lock assembly
PS-3550	Cam assembly
PS-3594	Quarter turn fasteners
PS-3595	Door latch
PS-3599	Door latch
PS-3604	Replacement keys for PS-3599/PS-3595
PS-4007	Capacitor
PS-4008	Capacitor
PS-4015	Capacitor
PS-4016	Capacitor
PS-4045	Capacitor
PS-4046	Capacitor
PS-4047	Capacitor
PS-4048	Capacitor
PS-4053	Capacitor
PS-4056	Resistor RNH 30 ohm
PS-4057	Resistor LDS 120 ohm
PS-4058	Capacitor
PS-4082	Capacitor

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
PS-4084	Capacitor
PS-4086	Resistor 1Kohm 3W axial led
PS-4087	Capacitor 2.2mf 400VDC Radial Lead
PS-4642	Modular terminal block
PS-4648	Control panel cover 18 x 29 SSRCP
PS-4812	Diodes
PS-5046	Incandescent light sockets
PS-5047	Red lens
PS-5048	Green lens
PS-5049	Amber lens
PS-5051	White lens
PS-5053	Clear lens (L1 L2)
PS-5054	Neon light base
PS-5055	Neon lamp - orange (L1 L3 L4)
PS-5056	Neon lamp - green (L2)
PS-5067	SSRCP jumpers min purchase 6
PS-5076	Rectifier - SUPERSEDED BY PS-5162
PS-5110	Base & Red LED 24V Flashing
PS-5111	LED - Red 28V
PS-5112	LED - Green 28V
PS-5113	LED - Yellow/Amber 28V
PS-5114	LED - Green 120V
PS-5115	LED - Red 120V
PS-5116	LED - White 120V
PS-5128	Red LED unit 28V
PS-5129	Green Bypass LED unit 28V
PS-5130	Yellow Bypass LED unit 28V
PS-5131	Red blinking Bypass LED 28V
PS-5132	Connector - 14 position
PS-5133	Connector - 16 position
PS-5151	Dual rectifier replaces 23P-1473 23P-1582 & PS-4870
PS-5152	Rectifier
PS-5162	Rectifier
PS-6161	DIN Rail
PS-715	Knob
PS-7345	Din Rail MX200
PS-8706	Black cover for MX50/90 processor board
PS-8895	OBSOLETE SEE PS-8896 SCR-N & SCR-E
PS-8896	SCR-N & SCR-E
PS-8903	SCR-N & SCR-E (600 VOLT)
Y110012	Voltmeter 0-600V Scale
Y120006	Frequency Meter 55-65Hz Scale
Y260099	3-Pole Control Relays 24Vdc Coil
Y500065	Incandescent Lamp 30Vdc Use on IDEC SLC40 type
Y500066	Green LED Lamp 24Vdc Use on IDEC SLC40 type
Y500067	Red LED Lamp 24Vdc Use on IDEC SLC40 type
Y500068	Amber LED Lamp 24Vdc Use on IDEC SLC40 type
Y600010	PT's secondary fuse 6A (250Vac Rated) Min purchase 5
Y600105	10A DC Fuse Fast acting type
Y600152	10A AC Fuse for Breaker trip coil Slow Blow

GE ZENITH COMMON PARTS LIST

to view prices and to order go to http://www.nooutage.com/ge_zenith_parts.htm

After parts are energized they are NOT returnable for refund. Defective parts can be exchanged.

PART NUMBER	DESCRIPTION
Y600169	15A AC Fuse for Breaker close coil Slow Blow
Y600172	PT's secondary fuse 2A (250Vac Rated) Min purchase 5
Z-4009	OBSOLETE NO REPLCMNT Coil - Sold as assembly
Z-4010	Coil - Sold as assembly
Z-4011	OBSOLETE NO REPLCMNT Coil - Sold as assembly
Z-4012	Coil - Sold as assembly
Z-4014	OBSOLETE NO REPLCMNT Coil - Sold as assembly
Z-4018	OBSOLETE NO REPLCMNT Coil - 120 V
Z-4019	OBSOLETE NO REPLCMNT Coil - 240 V
Z-4022	Coil - 277 V
Z-4023	OBSOLETE NO REPLCMNT Coil - 480 V
Z-5003	OBSOLETE NO REPLCMNT Coil - 120 V
Z-5005	OBSOLETE NO REPLCMNT Coil - 480 V
Z-5011	OBSOLETE NO REPLCMNT Coil - 24 V
Z-5013	OBSOLETE NO REPLCMNT Coil - 277 V
Z-5014	OBSOLETE NO REPLCMNT Coil - 208/240 V
ZNET10PS	Lon Works Power Supply (8-24 VAC/VDC)