

# Transfer Switches

OTPC PowerCommand®

40 - 3000 Amp 3 Pole and 4 Pole



**Optional Features Shown** 

# **Description**

Designed for continuous current operation and switching of electrical loads between primary power and standby generator sets, Cummins Power Generation Series OTPC PowerCommand automatic transfer switches monitor the primary power source, signal generator set startup, automatically transfer power, and return the load to the primary power source once the utility returns and is stabilized.

High-pressure silver alloy contacts can withstand thousands of switching cycles without burning, pitting, or welding. They require no routine contact maintenance and provide 100% continuous current ratings.

In **utility-to-genset applications**, the control system monitors utility and genset power. When utility power fails or is unsatisfactory, the switch starts the genset and transfers critical loads to the genset. The switch automatically transfers loads back to the utility when utility power returns.


In **utility-to-utility applications**, the control system monitors the primary utility source and transfers the critical load to a secondary utility source when primary power fails or is unsatisfactory. The switch automatically transfers loads back to the primary source when power is restored.

In **genset-to-genset applications**, the transfer switch automatically controls multiple gensets, allowing one genset to power the load with another genset as standby. The running (lead) unit can be selected manually or may be changed automatically with a built-in changeover timer.

#### **Features**

- Advanced Transfer Switch Mechanism Unique bidirectional linear actuator provides virtually friction-free, constant force, straight-line transfer switch action during automatic operation.
- PowerCommand Microprocessor Control A standard, fully featured microprocessor control with a choice of options. All features, settings, and adjustments are software-enabled for ease of setup and accuracy. Optically isolated logic inputs and high isolation transformers for AC power inputs provide high-voltage surge protection.
- Manual Operation Manual operating handles, shielded termination, and over-center type contact mechanisms allow effective, manual operation (40-1000A switches).
- Positive Interlocking Mechanical and electrical interlocking prevent source-to-source connection through the power or control wiring.
- Main Contacts Heavy-duty silver alloy contacts with separate arcing surfaces and multileaf arc chutes are rated for total system transfer including overload interruption.
- Easy Service/Access Plug connections, doormounted controls, ample access space, and compatible terminal markings. The control is field programmable.
- Product lines, Accessories and Services Cummins
   Power Generation offers a wide range of accessories
   and services to suit your requirements.
- Certifications Cummins Power Generation OTPC Transfer Switches are certified to a wide range of standards.
- Warranty Cummins Power Generation offers singlesource responsibility at both the factory and distributor levels for warranty, service, and parts support.

## **Transfer Switch Mechanism**



- A bi-directional linear actuator powers OTPC Transfer Switches. This design provides virtually friction-free, constant force, straight-line transfer switch action. No complex gears or linkages.
- Independent break-before-make action is used for both 3-pole and 4-pole/switched neutral switches. On 3-pole/switched neutral switches, this action also prevents the objectionable ground currents and nuisance ground fault tripping that can result from overlapping designs.
- A mechanical interlock prevents simultaneous closing of normal and emergency contacts. The action positively prevents dangerous source-to-source connections.
- Electrical interlocks prevent simultaneous closing signals to normal and emergency contacts and interconnection of normal and emergency sources through the control wiring.
- Long-life, high pressure, silver alloy contacts resist burning and pitting. Separate arcing surfaces further protect the main contacts. Contacts are mechanically held in both normal and emergency positions for reliable, quiet operation.

## Specifications-Transfer Switch Mechanism

Voltage Rating

**Arc Interruption** 

**Neutral Bar** 

**Auxillary Contacts** 

Operating Temperature Storage Temperature Humidity Altitude Surge Withstand Ratings

Total Transfer Time (source-to-source)

**Manual Operation Handles** 

Transfer switches rated from 40 A through 3000 A are rated up to 600 VAC, 50 or 60 Hz.

Multiple leaf arc chutes cool and quench the arcs. Covers prevent interphase flashover and are transparent for visual inspection. A full current-rated neutral bar with lugs is standard on enclosed 3-pole transfer switches.

Two contacts (one for each source) are provided for customer use. Wired to terminal block for easy access. Rated at 10A continuous and 250 VAC maximum.

-40°F (-40°C) to 140°F (60°C)

-40°F (-40°C) to 140°F (60°C)

Up to 95% relative, noncondensing

Up to 10,000 ft (3,000 m) without derating

Surge-tested for location category B3, per IEEE C 62.41. Testing per guidelines in IEEE 62.45. Control tested to European Surge Test EN 61000-4-5

Will not exceed 6 cycles at 60 Hz with normal voltage applied to the actuator and without programmed transition installed.

Transfer switches rated through 1000 A are equipped with permanently attached operating handles and quick-break, quick-make contact mechanisms suitable for manual operation. Transfer switches over 1000 A are equipped with manual operators for service use only under de-energized conditions.

# **PowerCommand Microprocessor Control**

## **Control Packages**

A choice of two control packages allows flexibility for determining the most suitable level of control for a given application:

| Level 1 Control  | Level 2 Control   |
|--|---|
| Utility-to-Genset Applications   | Utility-to-Genset Applications  |
|  | Utility-to-Utility Applications   |
|  | Genset-to-Genset Applications   |
| Software Adjustable Time Delays:   | Software Adjustable Time Delays:  |
| Engine Start: 0 - 15 sec   | Engine Start: 0 - 120 sec   |
| Transfer Normal to Emergency: 0 - 120 sec                                  | Transfer Normal to Emergency: 0 - 120 sec                               |
| Retransfer Emergency to Normal: 0 - 30 min                                 | Retransfer Emergency to Normal: 0 - 30 min                              |
| Engine Stop: 0 - 30 min  | Engine Stop: 0 - 30 min   |
| Programmed Transition: 0 - 60 sec  | Programmed Transition: 0 - 60 sec                                       |
| Undervoltage Sensing - 3-phase normal, 1-phase emergency                   | Over/Undervoltage Sensing - 3-phase normal and emergency                |
| Pickup: 85% to 98% of nominal voltage                                      | Pickup: 85% to 98% of nominal voltage                                   |
| Dropout: 75% to 98% of pickup setting                                      | Dropout: 75% to 98% of pickup setting                                   |
| Dropout Time Delay: 0.1 to 1.0 sec   | Dropout Time Delay: 0.1 to 1.0 sec                                      |
| Overvoltage Sensing - 3-phase normal, 1-phase emergency                    | Overvoltage Sensing - 3-phase normal and emergency                      |
| Dropout: 105% to 135% of nominal voltage                                   | Dropout: 105% to 135% of nominal voltage                                |
| Pickup: 95% to 99% of dropout setting                                      | Pickup: 95% to 99% of dropout setting                                   |
| Dropout Time Delay: 0.5 to 120 sec   | Dropout Time Delay: 0.5 to 120 sec                                      |
| Frequency Sensing  | Frequency Sensing   |
| Pickup: ±5% to ±20% of nominal frequency                                   | Pickup: ±5% to ±20% of nominal frequency                                |
| Dropout: ±1% beyond pickup   | Dropout: ±1% beyond pickup  |
| Dropout Time Delay: 0.1 to 15.0 sec  | Dropout Time Delay: 0.1 to 15.0 sec                                     |
|  | Voltage Imbalance Sensing   |
|  | Dropout: 2% to 10%  |
|  | Pickup: 90% of dropout  |
|  | Time Delay: 2.0 to 20.0 sec   |
|  | Phase Rotation Sensing  |
|  | Time Delay: 100 msec  |
|  | Loss of Single Phase Detection  |
|  | Time Delay: 100 msec  |
| Standard Open Transition Transfer Mode                                     | Standard Open Transition Transfer Mode                                  |
| Programmed Transition Transfer Mode  | Programmed Transition Transfer Mode                                     |
| <b>Programmable Genset Exerciser -</b> One event/schedule with or w/o load | Programmable Genset Exerciser - Eight events/schedules with or w/o load |
| Basic Indicator Panel  | Basic Indicator Panel   |
| Source Available/Connected LED Indicators                                  | Source Available/Connected LED Indicators                               |
| Test/Exercise/Bypass Buttons   | Test/Exercise/Bypass Buttons  |
|  | Digital Display   |
| Date/Time-Stamped Event Recording  | Date/Time-Stamped Event Recording                                       |
| Load Sequencing (optional with Network Communications Module)              | Load Sequencing (optional with Network Communications Module)           |

## **Time-Delay Functions**

**Engine Start:** Prevents nuisance genset starts in the event of momentary power system variation or loss. Not included in utility-to-utility systems.

**Transfer Normal to Emergency:** Allows genset to stabilize before application of load. Prevents power interruption if normal source variation or loss is momentary. Allows staggered transfer of loads in multiple transfer switch systems.

**Retransfer Emergency to Normal:** Allows the utility to stabilize before retransfer of load. Prevents needless power interruption if return of normal source is momentary. Allows staggered transfer of loads in multiple transfer switch systems.

**Engine Stop:** Maintains availability of the genset for immediate reconnection in the event that the normal source fails shortly after transfer. Allows gradual genset cool down by running unloaded. Not included in utility-to-utility systems.

**Programmed Transition:** Transfers load to neutral position, disconnected from sources, to allow inductive load voltages to decay.

# **Control Options**

#### **Relay Signal Module**

Provides an adjustable transfer, pending time delay of 0 to 60 seconds and Normal and Emergency status signals, to prevent interruption of power during elevator operation. Relay outputs include: Source 1 Connected and Available, Source 2 Connected and Available, Not in Auto, Test/Exercise Active, and Pending Transfer (elevator signal).

#### Loadshed

Removes the load from the emergency power source by driving the transfer switch to the neutral position when signaled remotely. Transfers load back to the emergency source when the signal contacts open. Immediate retransfer to the preferred source when it is re-established.

#### PowerCommand Network Interface

Provides connection to the PowerCommand network. LonWorks® compatible for integration into customer monitoring strategy.

#### **Load Power and Load Current Monitoring**

Measures load phase and neutral, current, power factor, real power (kW) and apparent power (kVA). Warns of excessive neutral current resulting from unbalanced or nonlinear loads.

#### **User Interfaces**

## **Basic Interface Panel**

LED indicators provide at-a-glance source and transfer switch status for quick summary of system conditions. Test and Override buttons allow delays to be bypassed for rapid system checkout.

#### **Digital Display**

The digital display provides a convenient method for monitoring load power conditions, adjusting transfer switch parameters, monitoring PowerCommand Network status, or reviewing transfer switch events. Password protection limits access to adjustments to authorized personnel. The digital display comes standard with the Level 2 PowerCommand microprocessor control, and is optional with the Level 1 Control.

## User Interface Options Front Panel Security Key

Front panel access can be locked out using this option. Prevents unauthorized transfers or testing. Prevents unauthorized adjustments via the digital display.

#### **Analog Bargraph Meter**

An LED bar graph display provides easy to read indication for Normal and Emergency voltages and frequencies, load currents, power factor, and Kilowatts. Green, amber, and red LED's provide at-a-glance indication of system acceptability. Available as an option with the Level 2 PowerCommand microprocessor control.

## **Enclosures**

The transfer switch and PowerCommand control are mounted in a single-door enclosure.

- · Key locking cabinet, UL tested and Type Rated
- Interface panels
- Wire bend space complies with 2002 NEC Table 312.6 (B).

# **Enclosure Dimensions - Transfer Switch in U.L. Type 1 Enclosure**

| Amp Rating    | Hei  | ight | Wie   | Width |      | Door Closed |      | Door Open |      | ight | Outline Drawing |
|---------------|------|------|-------|-------|------|-------------|------|-----------|------|------|-----------------|
|               | in   | mm   | in    | mm    | in   | mm          | in   | mm        | lb   | kg   |                 |
| 40, 70, 125   | 27.0 | 686  | 20.5  | 521   | 12.0 | 305         | 31.5 | 800       | 82   | 37   | 310-0544        |
| 150, 225      | 35.5 | 902  | 26.0  | 660   | 16.0 | 406         | 41.0 | 1042      | 165  | 75   | 310-0414        |
| 260           | 43.5 | 1105 | 28.5  | 724   | 16.0 | 406         | 43.0 | 1093      | 170  | 77   | 310-0540        |
| 300, 400, 600 | 54.0 | 1372 | 25.5  | 648   | 18.0 | 457         | 42.0 | 1067      | 225  | 102  | 310-1307        |
| 800, 1000     | 68.0 | 1727 | 30.0  | 762   | 19.5 | 495         | 48.5 | 1232      | 360  | 163  | 310-0417        |
| 1200          | 75.0 | 1905 | 36.0  | 915   | 21.5 | 546         | 54.0 | 1372      | 625  | 283  | 310-0482        |
| 1600, 2000(1) | 90.0 | 2286 | 36.0. | 915   | 48.0 | 1219        | 84.0 | 2134      | 1100 | 499  | 310-0483        |
| 3000(1)       | 90.0 | 2286 | 36.0  | 915   | 48.0 | 1219        | 84.0 | 2134      | 1250 | 567  | 310-0484        |

# Enclosure Dimensions - Transfer Switch in U.L. Type 3R, 4 or 12 Enclosure

| Amp Rating     | Height |      | Width |     | Door Closed |      | Door Open |      | Weight |     | Cabinet Type | Outline  |
|----------------|--------|------|-------|-----|-------------|------|-----------|------|--------|-----|--------------|----------|
|                |        | 9    |       |     |             |      |           |      |        |     |              | Drawing  |
|                | in     | mm   | in    | mm  | in          | mm   | in        | mm   | lb     | kg  |              |          |
| 40, 70, 125    | 34.0   | 864  | 26.5  | 673 | 12.5        | 318  | 36.5      | 927  | 125    | 57  | 3R, 12,      | 310-0453 |
| 40, 70, 125    | 34.0   | 864  | 26.5  | 673 | 12.5        | 318  | 36.5      | 927  | 125    | 57  | 4            | 310-0445 |
| 150, 225       | 42.5   | 1080 | 30.5  | 775 | 16.0        | 406  | 44.0      | 1118 | 215    | 97  | 3R, 12       | 310-0454 |
| 150, 225       | 42.5   | 1080 | 30.5  | 775 | 16.0        | 406  | 44.0      | 1118 | 215    | 97  | 4            | 310-0446 |
| 260            | 46.0   | 1168 | 32.0  | 813 | 16.0        | 406  | 46.0      | 1168 | 255    | 102 | 3R, 12       | 310-0455 |
| 260            | 46.0   | 1168 | 32.0  | 813 | 16.0        | 406  | 46.0      | 1168 | 255    | 102 | 4            | 310-0447 |
| 300, 400, 600  | 59.0   | 1499 | 27.5  | 699 | 16.5        | 419  | 41.5      | 1054 | 275    | 125 | 3R, 12       | 310-1315 |
| 300, 400, 600  | 59.0   | 1499 | 27.5  | 699 | 16.5        | 419  | 41.5      | 1054 | 275    | 125 | 4            | 310-1316 |
| 800, 1000      | 73.5   | 1867 | 32.5  | 826 | 19.5        | 495  | 49.5      | 1257 | 410    | 186 | 3R, 12       | 310-0457 |
| 800, 1000      | 73.5   | 1867 | 32.5  | 826 | 19.5        | 495  | 49.5      | 1257 | 410    | 186 | 4            | 310-0449 |
| 1200           | 75.0.  | 1905 | 36.0  | 915 | 19.5        | 495  | 55.0      | 1397 | 450    | 204 | 3R, 12, 4    | 310-0482 |
| 1600, 2000 (1) | 90.0   | 2286 | 32.5  | 826 | 51.0        | 1295 | 79.0      | 2007 | 1100   | 499 | 3R, 12, 4    | 310-0744 |
| 3000 (1)       | 90.0   | 2286 | 38.0  | 965 | 51.0        | 1295 | 84.5      | 2146 | 1250   | 567 | 3R, 12, 4    | 310-0745 |

Note 1: Rear or side access is required to complete power wiring installations.

# Enclosure Dimensions - Transfer Switch in U.L. Type 4X Stainless Steel 316 Enclosure

| Amp Rating    | Hei  | ght  | Wi   | dth | Door ( | Closed | Door | Open | We  | ight | Cabinet Type | Outline<br>Drawing |
|---------------|------|------|------|-----|--------|--------|------|------|-----|------|--------------|--------------------|
|               | in   | mm   | in   | mm  | in     | mm     | in   | mm   | lb  | kg   |              |                    |
| 40, 70, 125   | 46.0 | 1168 | 32.0 | 813 | 16.0   | 406    | 46.0 | 1168 | 255 | 102  | 4X           | 310-0447           |
| 150, 225      | 46.0 | 1168 | 32.0 | 813 | 16.0   | 406    | 46.0 | 1168 | 255 | 102  | 4X           | 310-0447           |
| 260           | 46.0 | 1168 | 32.0 | 813 | 16.0   | 406    | 46.0 | 1168 | 255 | 102  | 4X           | 310-0447           |
| 300, 400, 600 | 73.5 | 1867 | 32.5 | 826 | 19.5   | 495    | 49.5 | 1257 | 410 | 186  | 4X           | 310-0449           |
| 800, 1000     | 73.5 | 1867 | 32.5 | 826 | 19.5   | 495    | 49.5 | 1257 | 410 | 186  | 4X           | 310-0449           |

Note: Not available 1200 - 3000 Amp..

# **Transfer Switch Lug Capacities**

All lugs accept copper or aluminum wire unless indicated otherwise.

| Amp Rating  | Cables Per Phase | Size                              |
|-------------|------------------|-----------------------------------|
| 40, 70, 125 | 1                | #12 AWG-2/0                       |
| 150, 225    | 1                | #6 AWG - 300 MCM                  |
| 260         | 1                | #6 AWG - 400 MCM                  |
| 300, 400    | 1                | 3/0 - 600 MCM                     |
| 300, 400    | 2                | 3/0 - 250 MCM                     |
| 600         | 2                | 250 - 500 MCM                     |
| 800 - 1000  | 4                | 250 - 500 MCM                     |
| 1200        | 4                | #2 AWG to 600 MCM                 |
| 1600, 2000  | 8                | #2 AWG to 600 MCM (lugs optional) |
| 3000        | 8                | #2 AWG 600 MCM (lugs optional)    |

Caution: Do not run control wiring through power cable conduit or raceway.

# **UL Withstand and Closing Ratings**

The transfer switches listed below must be protected by circuit breakers or fuses. Reference drawings include detailed listings of specific breakers or fuse types that must be used with the respective transfer switches. Consult with your Distributor/Dealer to obtain the necessary drawings. Withstand and Closing Ratings (WCR) are stated in symmetrical RMS amperes.

|                              | MC   | CB PROTECTION      | ON                   | CURRENT LIMITED BREAKER PROTECTION                  |                   |                   |  |  |  |
|------------------------------|--|--------------------|----------------------|---|-------------------|-------------------|--|--|--|
| Transfer<br>Switch<br>Ampere | WCR@Volts Max<br>with Specific<br>Manufacturers<br>MCCBs | Max MCCB<br>Rating | Drawing<br>Reference | With Specific<br>Current Limiting<br>Breakers (CLB) | Max CLB<br>Rating | Drawing Reference |  |  |  |
| 40 - 125                     | 14,000 @ 480   | 225 A              | 098-6885             | 200,000 @ 480                                       | 225 A             | 098-6918          |  |  |  |
| 40 - 125                     | 14,000 @ 600   | 225 A              | 098-6885             | 100,000 @ 600                                       | 225 A             | 098-6918          |  |  |  |
| 150 - 260                    | 30,000 @ 480   | 400 A              | 098-6886             | 200,000 @ 480                                       | 400 A             | 098-6919          |  |  |  |
| 150-260                      | 30,000 @ 600   | 400 A              | 098-6886             | 100,000 @ 600                                       | 400 A             | 098-6919          |  |  |  |
| 300 - 600                    | 65,000 @ 480   | 1200 A             | 098-6887             | 200,000 @ 480                                       | 1200 A            | 098-6920          |  |  |  |
| 300 - 600                    | 65,000 @ 600   | 1200 A             | 098-6887             | 100,000 @ 600                                       | 1200 A            | 098-6920          |  |  |  |
| 800 - 1000                   | 65,000 @ 480   | 1400 A             | 098-6888             | 150,000 @ 480                                       | 1400 A            | 098-6921          |  |  |  |
| 800 - 1000                   | NA   | NA                 | 098-6888             | 100,000 @ 600                                       | 1400 A            | 098-6921          |  |  |  |
| 1200                         | 85,000 @ 480   | 1600 A             | 098-7312             | 85,000 @ 480  | 1600 A            | 098-7312          |  |  |  |
| 1200                         | 65,000 @ 600   | 1600 A             | 098-7312             | 65,000 @ 600  | 1600 A            | 098-7312          |  |  |  |
| 1600 - 2000                  | 100,000 @ 480  | 4000 A             | 098-7311             | 100,000 @ 480                                       | 4000 A            | 098-7311          |  |  |  |
| 1600 - 2000                  | 85,000 @ 600   | 4000 A             | 098-7311             | 85,000 @ 600  | 4000 A            | 098-7311          |  |  |  |
| 3000                         | 100,000 @ 480  | 4000 A             | 098-7313             | 100,000 @ 480                                       | 4000 A            | 098-7313          |  |  |  |
| 3000                         | 85,000 @ 600   | 4000 A             | 098-7313             | 85,000 @ 600  | 4000 A            | 098-7313          |  |  |  |

|                              |  | FUSE PROTECTION          |                      |
|------------------------------|--|--------------------------|----------------------|
| Transfer<br>Switch<br>Ampere | WCR @ Volts<br>Max. with Current<br>Limiting Fuses | Max Fuse, Size and Type  | Drawing<br>Reference |
| 40 - 125                     | 200,000 @ 480                                      | 200 A Class, J, RK1, RK5 | 098-6885             |
| 40 - 125                     | 200,000 @ 600                                      | 200 A Class, J, RK1, RK5 | 098-6885             |
| 150 - 260                    | 200,000 @ 480                                      | 600 A Class, J, RK1, RK5 | 098-6886             |
| 150-260                      | 200,000 @ 600                                      | 1200 A Class L           | 098-6886             |
| 300 - 600                    | 200,000 @ 480                                      | 1200 A Class L           | 098-6887             |
| 300 - 600                    | 200,000 @ 600                                      | 1200 A Class L           | 098-6887             |
| 800 - 1000                   | 200,000 @ 480                                      | 2000 A Class L           | 098-6888             |
| 800 - 1000                   | 200,000 @ 600                                      | 2000 A Class L           | 098-6888             |
| 1200                         | 200,000 @ 480                                      | 3000 A Class L           | 098-7312             |
| 1200                         | 150,000 @ 600                                      | 3000 A Class L           | 098-7312             |
| 1600 - 2000                  | 200,000 @ 480                                      | 2500 A Class L           | 098-7311             |
| 1600 - 2000                  | 150,000 @ 600                                      | 2500 A Class L           | 098-7311             |
| 3000                         | 200,000 @ 480                                      | 4000 A Class L           | 098-7313             |
| 3000                         | 150,000 @ 600                                      | 4000 A Class L           | 098-7313             |

## Submittal Detail

#### **Automatic Transfer Switch Options**

#### **Current Ratings** [] S046 40 Amps [] S047 70 Amps [] S048 125 Amps [] S049 150 Amps [] S050 225 Amps [] S051 260 Amps [] S052 300 Amps [] S053 400 Amps [] S054 600 Amps [] S055 800 Amps [] S056 1000 Amps [] S057 1200 Amps [] S058 1600 Amps [] S059 2000 Amps [] S060 3000 Amps Voltage (Line-Line) Ratings [] R020 120 Volts(\*) [] R038 190 Volts [] R021 208 Volts [] R022 220 Volts [] R023 240 Volts [] R024 380 Volts [] R025 416 Volts [] R035 440 Volts [] R026 480 Volts [] R027 600 Volts (\*): Line to Neutral Voltage (not available on 1200 - 3000 amp switches) **Pole Configuration** [] A028 Poles - 3 (Solid Neutral) [] A029 Poles - 4 (Switched Neutral - not available 40 - 125 amps) Frequency [] A044 60 Hertz [] A045 50 Hertz Application [] A035 Appl - Utility to Genset [] A036 Appl - Utility to Utility [] A037 Appl - Genset to Genset **System Options** [] A041 Single Phase, 2-wire or 3-wire (not available 1200-3000 amps) [] A042 Three Phase, 3-wire or 4-wire **Enclosure** [] B001 Type 1: General purpose indoor (similar to IEC type IP30) [] B002 Type 3R: Intended for outdoor use (dustproof and rainproof) (Similar to IEC type IP34) [] B003 Type 4: Indoor or outdoor use (watertight) (Similar to IEC type IP65) [] B004 Open Construction: No enclosure - includes Automatic Transfer Switch and Controls. [] B010 Type 12: Indoor use, dust-tight and drip-tight (similar to IEC type IP61) [] B025 Type 4X: Indoor or outdoor use (watertight) (similar to IEC Type IP65) (Not available 1200-3000 Amps) Listing [] A046 Listing - UL 1008/CSA Certification [] A064 Listing - NFPA 20 (not available 1200-3000 amps)

| Options and Accessories  |
|--|
| Controls   |
| [] C023 Switch Control - Level 1   |
| [] C024 Switch Control - Level 2   |
| Control Options  |
| [] M017 Security Key - Front Panel   |
| [] M018 Display - Digital  |
| [] M022 Monitoring - Load  |
| [] M023 Module - Relay   |
| [] M031 Communications - Lon Works Network Communications Module (FTT-10)                                    |
| Meters   |
| [] D009 Digital Bar Graph Meters   |
| Battery Chargers   |
| [] K001 Battery Charger - 2 Amps, 12/24 Volts  |
| [] K002 Battery Charger - 10 Amps, 12 Volts  |
| [] K003 Battery Charger - 10 Amps, 24 Volts  |
| Auxiliary Relays - Relays are UL-Listed and factory installed. All   |
| relays provide (2) normally open and (2) normally closed isolated  |
| contacts rated 10A @ 600 VAC Relay terminals accept (1) 18 Ga. to  |
| (2) 12 Ga. wires per terminal.   |
| [] L101 Aux. Relay - 24 VDC Coil - Installed, not wired (for customer  |
| use).  |
| [] L102 Aux. Relay - Emergency Position - Relay energized when   |
| OTPC in Source 2 (Emergency) position  |
| [] L103 Aux. Relay - Normal Position - Relay energized when OTPC in Source 1 (Normal) position               |
| [] L201 Aux. Relay - 12 VDC Coil Installed, not wired  |
| [] L202 Aux. Relay - Emergency Position - Relay energized when   |
| OTPC in Source 2 (Emergency) position  |
| [] L203 Aux. Relay - Normal Position - Relay energized when OTPC   |
| in Source 1 (Normal) position  |
| [] L204 Aux. Relay - GenSet Start Contacts   |
| Applications Modules   |
| [] M003 Terminal Block - 30 points (not wired)   |
| [] M007 Load Shed - From Emergency - Drives OTPC in neutral  |
| position when remote signal contact closes   |
| [] N002 Terminal Block - Battery Charger Alarms  |
| [] N008 Terminal Lugs - Cable (1600 - 3000 amps only) [] N009 Power Connect - Bus Stabs (150 - 1200 amp open |
| construction only)   |
| Shipping Option  |
| [] A051 Packing - Export Box   |
| [] NO13 Extension Harness  |

[] N013 Extension Harness

## **Available Products and Services**

A wide range of products and services is available to match your power generation system requirements. Cummins Power Generation products and services include:

- Diesel and Spark-Ignited Generator Sets
- Transfer Switches
- Bypass Switches
- Parallel Load Transfer Equipment
- Digital Paralleling Switchgear
- PowerCommand Network and Software
- Distributor Application Support
- Planned Maintenance Agreements

# Warranty

All components and subsystems are covered by an express, limited one-year warranty. Extended factory warranties and local distributor maintenance agreements are also available.

## Certifications


Transfer switches meet or exceed leading code requirements:

**NEMA** - All switches comply with NEMA ICS 10

ISO9001 - This transfer switch was designed and manufactured in facilities certified to ISO9001



CSA - All switches are CSA certified up to 600 VAC



**UL** - All switches are UL 1008 Listed, and factory or field installed switch accessories comply with UL Listing; UL Type Rated cabinets; UL Listed CU-AL terminals

# See your distributor for more information



Cummins Power Generation 1400 73rd Avenue N.E. Minneapolis, MN 55432 763.574.5000

Fax: 763.574.5298

Cummins Power Generation is a subsidiary of Cummins Inc. PowerCommand is a registered trademark of Cummins Power Generation. LonWorks is a registered trademark of Echelon.

**Warning:** Backfeed to a utility system can cause electrocution and/or property damage. Do no connect to any building's electrical system except through an approved device or after building main switch is open.